

Carpet & Upholstery Cleaner Concentrate

COVERAGE: One gallon will cover approximately 10,000 sq. ft.

ENVIRONMENTALLY SAFER - This product meets the Green Seal™ environmental standard for industrial and institutional cleaners based on its reduced human and environmental toxicity and reduced volatile organic compound content.

PROCYON products have been tested and approved for indoor air quality; our products contain no volatile organic compounds (NO VOC's) and no fragrance has been added. PROCYON can be used in enclosed areas without the worry of harmful off gases.

CONTAINS: nonionic surfactant, water softening agents and natural degreasers.

TEST FOR COLOR FASTNESS: Prior to cleaning, test an out of the way area of carpet & upholstery to insure color fastness. Apply a small amount of mixed, ready-to-use PROCYON to the area, wait one minute and blot with a white cotton towel (BLEACH FREE). Check for color fastness. User assumes all liability and risk. Using more is NOT better. Use as directed.

NOTE: THE HOTTER THE WATER THE MORE EFFECTIVE THE CLEANING.

DIRECTIONS: Vacuum thoroughly. For home use, follow directions for Portable Extraction.

PRE-SPRAY/EXTRACTION: For use on heavily soiled carpet traffic areas. Effectively dissolves grease, dirt, grime, spots and stains. Mix 4 oz. to 1 gallon of COLD, WARM or HOT water. Pre-spray evenly. DO NOT OVER WET. Let dwell for 10 minutes. **Extract with fresh water.**

PORTABLE EXTRACTION (without pre-spray): Mix 4 oz. to 1 gallon of COLD, WARM or HOT water. For all portable extractors including extractors with a siphon tube. In this case, simply place the siphon tube into the concentrated liquid.

BONNET CLEANING: Mix 4 oz. to 1 gallon of COLD, WARM or HOT water. Pre-spray evenly on heavily soiled area. Let dwell for 10 minutes. For best results, bonnet using 100% cotton bonnet pads.

WICKING & BROWNING: Mix 2 oz. to 1 gallon of COLD, WARM or HOT water. Pre-spray the carpet fiber. DO NOT OVER WET. Let dwell for 10 minutes. For best results bonnet using 100% cotton bonnet pads to absorb moisture and to prevent wicking or browning problems.

UPHOLSTERY: Mix 2 oz. to 1 gallon of COLD or WARM water. Pre-spray evenly, applying from the base of the upholstery going up and extract from the top going down.

HYDRO FORCE: Mix 32 oz. to 1 gallon of WARM or HOT water (meter 1:8). Apply evenly. Let dwell for 10 minutes.

TRUCK MOUNT: Fresh water rinse. Set heat at 180° to 200° NOTE: Rinsing agents are not needed.

CAUTION: Do not use on varnished surfaces, leather, or vinyl. This product will strip protective finishes if allowed to puddle. **PERSONAL PROTECTIVE EQUIPMENT:** Protective gloves to minimize skin contact. Wash hands after using to avoid skin drying out. **FIRST AID:** In case of eye contact flush eyes with fresh water for 15 minutes. If swallowed, rinse mouth with plenty of water. If irritation persists, seek prompt medical help. **IMPROPER USE** may lead to adverse health effects. **WASTE DISPOSAL METHOD:** Dispose of in a landfill in accordance with all local, state, and federal regulations.

- Odor Free
- No VOCs
- No Enzymes
- Nontoxic
- Colorless
- Hypoallergenic
- No Soapy Sticky Residue
- Concentrate pH 9.3
- RTU pH 9.3



No VOCs



GS-37 2008

PROCYON
Soap Free

Proud Member Of:



Plus Manufacturing, Inc. PO Box 7288 Spokane, WA 99207
(509) 466-8045 * 800-PROCYON (776-2966) * Fax (509) 484-0418
Email plusmfg@msn.com * www.soapfreeprocyon.com